



USING THE LCD VEST

The italicized words below are identified above

1. Use the *neck strap* to hang the *chest plate* around your neck. Adjust the *neck strap* so the pad rests on the back of the neck and the *chest plate* rests high on your chest.
2. Use the *chest strap* to hold the *plate* to your chest. Adjust the strap for comfort.
3. Attach your *LCD monitor* to the end of the *goose neck*.
4. Use the *ball joint adjustment knobs* to place the monitor in the best position.